

OCTOBER 18-20
POSTILLION CONVENTION CENTRE
WTC ROTTERDAM



Exergy analysis of polymer flooding in clastic reservoirs

Anas. M. Hassan, Hans Bruining, Tagwa Musa, Rouhi Farajzadeh.






Agenda – Contents

- Introduction
 - Energy outlook (view to 2040)
 - What can be done?
- Objective/ scope of the project
- EOR-polymer flooding
- Why exergy analysis?
- Bio-polymer model(s) results
- Conclusions

Energy Outlook - view to 2040


Energy-related CO₂ emissions peak Global share of primary energy




To which extend can the oil and gas industry contribute to this transition (ERoEI)?


- Exergy can be used to determine whether improved oil recovery is more efficient than conventional oil recovery and therefore reduce the carbon footprint by ~ 1%
- The possibility to compare energy invested to realize recovery for enhanced and conventional recovery.
- To define marking point (exergy-zero time recovery) when the exergy invested and exergy recovered become the same.


Objective / scope



Polymer flooding







Benefits:


- Enhanced oil recovery up to 30%.
- Decreasing the mobility ratio (M)
- Sweep efficiency (no fingring).
- Less water required for injection.
- Where: κ = permeability; λ = mobility; μ = viscosity.

M > 1
(Fingering)
Before Polymer
Flooding


M < 1
(Favorable)
After Polymer
Flooding

$$M = \frac{\lambda_{water}}{\lambda_{oil}} = \frac{\kappa_{water} / \mu_{water}}{\kappa_{oil} / \mu_{oil}}$$

Exergy Analysis



EOR-polymer based system (PBS)



Main exergy contributors of PBS

Drilling exergy

Crushing energy 116 [MJ/m] (PM)

Tubing / Casing

35.8 [GJ/ton-steel] (PM)

Recovery exergy

 u_{inj} [m/s] × 10.7 × 10³ [kWh/m³-oil] × (1-f_w) [-] = u_{inj} × 3.85 × 10¹⁰ [J/m³] × (1-f_w) [W/m²] Gained-exergy

Polymer exergy

Manufacturing costs: neglect c ≤ 1200 [ppm]

Circulation exergy

 $3 \times \int_{0}^{length} dxuinj[m/s] \Delta P[J/m^3]$ [W/m²]
Invested-exergy

Labour cost

0.215 [€/kWh] ≈ 59.7 [€/GJ] (Mackay, 2008)



Enhanced Oil Recovery (EOR)

Scenario 1

Water Injection

- Water injection during the entire process
 - c = 0

Scenario 2

Polymer Injection

- Constant natural polymer injection during the entire process
 - $c = c_{bound} = 0.001$

Scenario 3

Slug Injection

- Time dependent slug injection
- $C_{bound} \times [tannh(t tijd1) tnnh(t tijd2)]$ where, tannh(x) $(0.5+0.5) \times tannh(x/\delta)$ where, $\delta = 0.1$
- tijd2= 3x10 [s] & tijd2= 6x10 [s]


COMSOL MODEL- architecture

 $\varphi \partial_t S_W + \partial_\chi (uinjfw) = 0$ $\varphi \partial_t (cS_W) + \partial_\chi (uinjcfw) = 0$ where: φ = porosity, S_W = water saturation, c = polymer-Concentration, u_{inj} = injection velocity, f_W = fractional flow function;

$$f_{w}^{\gamma}(Sw,c) = \frac{k_{rw}(Sw)/\mu_{w}(c;\gamma)}{\frac{k_{rw}(Sw)}{\mu_{w}(c;\gamma)} + \frac{k_{ro}}{\mu_{o}}},$$


where: k_r =relative permeability, μ = viscosity

Accumulation, Convection, Diffusion




* Weak Form1 (Water): $\varphi \partial(S,t) \times test(S) - u_{inj} \times fw(S,c) \times test(Sx) + \left(\frac{1}{Pe}\right) \times (S_x) \times test(Sx)$ * Weak Form2 (Polymer): $\varphi \partial(cS,t) \times test(c) - u_{inj} \times cfw(S,c) \times test(cx) + \left(\frac{1}{Pe}\right) \times (Sc_x) \times test(cx)$


Results - analytical vs numerical




Results - Recovery Exergy (RF)




Results - Scenario 1




Results - Scenario 2



Results - Scenario 3



Results - Invested Exergy



Conclusions

Using a 1-D model of polymer displacement it is possible to analyze the exergy (maximum attainable work) balance of viscosified water injection.

The circulation exergy is the major contributor, i.e. it exceeds the exergy costs for drilling, casing, tubing and cleaning.

The analysis shows that (bio)-polymer injection leads to slightly higher exergy costs for circulation of the fluids, but can for the conditions considered accelerate the production.

A consideration for more cases is necessary to decide whether permanent polymer injection can compete with optimized slug injection.

The analysis shows that at the end of the project (concept of exergy-zero recovery time), for each scenario the termination point is reached when circulation exergy equal the recovery exergy.

Questions?

Backup slides

Energy Outlook - view to 2040

- Modern energy is one of most complex endeavors
- World demographic shift (from 7.3 to 9.1 billion in 2040)
- World economy doubles over the next 20 years (3.4%)
 - Global productivity will effectively double (GDP per person)
 - Growth in number of middle class families (2 billion)
 - Emerging economy powers (i.e., China, India)
- Global demand (700 quadrillion BTUs in 2040 ~ 25%)
- Oil remains the primary fuel ~ 60% (transport, industry)
- Global CO₂ emissions
 - Global CO₂ emissions rose close to 40% from 2000 to 2015
 - Global CO2 emissions are likely to peak (2015 to 2040)

Why exergy analysis?

- Exergy is a measure of the ability to produce useful work (potential work) from a quantity or flow (i.e. mass, heat) in specific environment (T, P, compositions).
- Energy (quantity) vs. Exergy (quantity & quality): Performing energy/ exergy balances and evaluating process efficiencies.
- Exergy of products = Exergy of resources Exergy losses

- Combined FLT & SLT
- Measure quantity & quality


Analysis

- Direction & reversibility aspects.
- Exergy degradation (loss/ irreversibility)



 $\dot{Ex} = \dot{Ex}^{ke} + \dot{Ex}^p + \dot{Ex}^{ph} + \dot{Ex}^{ch} ; Ex_{RF} = \frac{(Ex_{gained} - Ex_{invested})}{(Ex_{RF} + Ex_{RF})}$


Growth Opportunities for EOR-polymer Demand




Source: Forst & Sullivan, 2012. Revenue in 2019 (\$ Million)

Analysis of Enhanced Oil Recovery Chemical Market in The United States and Europa.


Results - Oil production rate



Results - Cumulative oil production



Results - Dissipated pump power



Results - Ratio [-]

